

Thermometer settings in English

On/off

Press button. C° or F° will display and then stop.

C° or F°

To choose between C° or F°, press button for 3 second for change. The change will be saved. To change back, press button again 3 sec.

Enter SETTINGS menu

In SETTINGS you can change the following, SLEEP, LOCK SCREEN, RATE OF CHANGE and RESET the thermometer. See description below.

Press button 5 second Menu text scrolls "SETTINGS", followed by features. To switch feature, press button short. To select one of the features, press button for 1 second, when it displays.

Feature SLEEP

Allows you to change how long you want it to take before it is automatically turned off. It is preset to 60 seconds.

Press button 1 sec to select when SLEEP is shown in the display. Press button to switch between 30, 60 and 120 sec. Press 1 sec to select desired value. Value flashes and is saved.

Feature LOCK SCREEN

Allows you to lock the screen if you do not want the screen to flip when you turn the thermometer. The preset is a flipping screen.

Press button 1 sec to select. Press button to switch between YES or NO. Press 1 sec to select desired value. Value flashes and is saved.

Feature RATE OF CHANGE

Allows you to change the speed of the display, if you want it to be slower. Preset is high speed.

Press button 1 sec to select. Press button to switch between HI or LO. Press 1 sec to select desired value. Value flashes and is saved.

Feature RESET

Allows you to easily change back all features to how it was preset from the beginning.

Press button 1 sec to select. Press button to switch between YES or NO. Press 1 sec to select desired value. Value flashes and is saved.

Exit SETTINGS menu - END

Press button to select END. Press button for 1 second to end settings, it saves all changes you made and the thermometer switches back to temperature mode automatically.